

DYNAC III 420104

<u>#</u>	<u>DESCRIPTION</u>	<u>CATALOG NUMBER</u>	<u>REFERENCE NUMBER</u>
N/A	Operator's manual	422929	~
1	Motor assembly (120V)	421242	42010403
2	Motor brush assembly (2pk)	421132	42000102
3	Motor gasket	421210	42010302
4	Interrupter assembly	421234	42010326
6	Tachometer PC board	421243	42010404
7	Feet (4pk)	421204	42010113
8	Fuse holder assembly	421229	42010321
8a	Fuse	421241	42010402
10	Lid bumpers (3 pk)	421203	42010112
11	Latch assembly	421245	42010406
14	Solenoid assembly	421248	42010409
15	Switch assembly	421254	42010416
17	Main PC board assembly	421250	42010412
19	Brake resistor	421252	42010414
20	Line cord assembly	421253	42010415
N/A	Lid open tool	421240	42010401
N/A	Rotor nut and hardware	421202	~
<u>Discontinued parts</u>			
9	Lid assembly	<i>discontinued 8/02</i> 421244	42010405
12	Lid cushion	<i>discontinued 8/02</i> 421246	42010407
13	Latch plate	<i>discontinued 8/02</i> 421247	42010408
16	Solenoid cover	<i>discontinued 8/02</i> 421249	42010411
18	Front panel assembly	<i>discontinued 8/02</i> 421251	42010413
5	Vibration Isolator	Not Available	~

DYNAC III 420104

