



# BD ProbeTec™ ET Swab Specimen Collection and Transport

- Amplified DNA probe test for chlamydia
- Amplified DNA probe tests for chlamydia and gonorrhea


## Female Endocervical Swab



1. Remove excess mucus with cleaning swab and discard.




2. Insert the Culturette™ Direct Swab into the cervical canal and rotate for 15 – 30 seconds.




3. Immediately place cap/swab into transport tube.

4. Make sure cap is tightly secured to tube.


## Male Urethral Swab



1. Insert the Mini-Tip Culturette™ Direct Swab 2 – 4 cm into the urethra.



2. Rotate for 3 – 5 seconds.



5. Label tube with patient information and date/time collected.

## Storage and Transport

Store and transport at 2 - 27°C.

Specimens must be processed within 4 - 6 days if stored at 2 - 27°C.

Specimens must be processed within 30 days if stored at 2 - 8°C.

220142—BD ProbeTec™ ET *Chlamydia trachomatis/Neisseria gonorrhoeae* (CT/GC) Amplified DNA Assay Collection Kit for Endocervical Specimens

220143—BD ProbeTec™ ET *Chlamydia trachomatis/Neisseria gonorrhoeae* (CT/GC) Amplified DNA Assay Collection Kit for Male Urethral Specimens

BD, BD Logo and all other trademarks are property of Becton, Dickinson and Company. ©2008 BD  
1-2733 December 2008 Printed in USA



**BD Diagnostics**  
7 Loveton Circle  
Sparks, MD 21152-0999  
800.638.8663  
www.bd.com/ds