



# BD ProbeTec™ ET Wet Swab Specimen Collection and Transport

- Amplified DNA probe test for chlamydia
- Amplified DNA probe tests for chlamydia and gonorrhea

## Female Endocervical Swab




1. Remove excess mucus with cleaning swab and discard.




2. Insert the Female Endocervical Swab into the cervical canal and rotate for 15 to 30 seconds.

## Male Urethral Swab



1. Insert the Male Urethral Swab 2 to 4 cm into the urethra.




2. Rotate for 3 – 5 seconds.

## Storage and Transport


Store and transport at 2 - 27°C.

Specimens must be processed within 4 - 6 days if stored at 2 - 27°C.


Specimens must be processed within 30 days if stored at 2 - 8°C.




3. Place swab in tube.



4. Break shaft at score line.



5. Screw cap firmly onto tube.



6. Label tube with patient info and date/time collected.



**BD Diagnostics**  
7 Loveton Circle  
Sparks, MD 21152-0999  
800.638.8663  
www.bd.com/ds

220142—BD ProbeTec™ ET *Chlamydia trachomatis*/  
*Neisseria gonorrhoeae* (CT/GC) Amplified DNA Assay  
Collection Kit for Endocervical Specimens

220143—BD ProbeTec™ ET *Chlamydia trachomatis*/  
*Neisseria gonorrhoeae* (CT/GC) Amplified DNA Assay  
Collection Kit for Male Urethral Specimens